

# AN-16 Application Note

750 Naples Street • San Francisco, CA 94112 • (415) 584-6360 • http://www.pumpkininc.com

# Salvo Messages, Memory Models and Keil's Cx51 C Compiler

#### Introduction

One of the many attractions of Salvo, The RTOS that runs in tiny places<sup>TM</sup>, is how easy it makes intertask communications, e.g. by enabling you to pass *messages* between tasks.

The 8051 and its derivatives support a wide range of memory areas, including internal and external data memory. Through the use of language extensions called *memory types*, Keil's Cx51 compiler enables you as the programmer to place variables in these data memory areas. Salvo messages use *message pointers*, which can point to anywhere in RAM or ROM. Therefore to use messages, you must be comfortable with *pointers* and Cx51's memory types.

This Application Note explains how to use Salvo message pointers with Cx51's various memory models.

## **Default Memory Types**

When building an application with Cx51, you must specify the *memory model* to be used. SMALL, COMPACT and LARGE are the choices. The memory model affects the location of each declared variable, function argument and automatic variable unless its memory type (see Cx51's Explicitly Declared Memory Types, below) has been explicitly specified. Cx51's *default memory types* are listed in Table 1:

# **Application Note**

| Memory<br>Model | Default<br>Memory Type | RAM Memory<br>Area Used              | Accessed via          |
|-----------------|------------------------|--------------------------------------|-----------------------|
| SMALL           | data                   | internal,<br>0x00-0x7F               | direct                |
| COMPACT         | pdata                  | external, 0xxx00-0xxxff <sup>2</sup> | MOVX @Rn <sup>3</sup> |
| LARGE           | xdata                  | external                             | MOVX @DPTR            |

Table 1: Default Memory Types for Selected Memory Model

### **Cx51's Explicitly Declared Memory Types**

As illustrated in Table 1, changing the memory model alters the default memory type, and thereby the location of any objects (declared variables, function arguments and/or automatic variables) lacking an explicitly declared memory type. This affects the use of pointers and their proper declaration.

In all of Cx51's memory models, the default memory type can be overridden on a per-object basis by explicitly declaring the object's memory type (and hence its location) using one of Cx51's code, data, idata, bdata, xdata, far or pdata memory types.

### **Simply Typed Objects**

Below are some simple variable declarations in C. First, here's a long int located in directly accessible internal data memory:

```
long int data pos;
```

Here's an int in indirectly accessible internal data memory:

```
int idata mem;
```

Here's an array of static chars (a string) in external data memory:

```
static char xdata strRc[SIZEOF_STR_RESP+1] = "\0";
```

These examples are easily understood, and once declared with the proper memory type, you can access an object without worrying which memory area it's located in.

You can use C's typedef to make your code easier to read and more robust. For example,



```
typedef char data TYPE_DATA;
```

defines a type TYPE\_DATA of char objects in directly accessible internal data memory. Declaring

```
TYPE_DATA temp1, temp2, temp3, temp4;
```

will place four char variables named temp1-temp4 in the first 128 bytes of the 8051's internal RAM. You can now use TYPE\_DATA throughout your code when declaring char variables in directly accessible internal data memory. If you choose to move all of those variables to another memory area, then changing the data memory type in the typedef is all that is necessary.

# Pointers, Explicitly Typed Pointers and Pointers to Explicitly Typed Objects

Learning to use pointers with the various memory types may require additional study. Here's an idata pointer to a char data. Both the pointer and the char are located in internal memory:

```
char data * idata charP;
```

Here's an xdata pointer to a data char, i.e. the pointer is located in external RAM, but the char it points to is in internal RAM:

```
char data * xdata charP;
```

This is the same thing:

```
data char * xdata charP;
```

Here's a pointer to a char, both of which are in external RAM:

```
char xdata * xdata charP;
```

Lastly, here's a pointer to a pointer to a char, all in separate RAM areas:

```
char data * idata charP * xdata charPP;
```

### **Salvo's Message Pointers**

Suppose you're using a Salvo *message queue* to communicate between two tasks. Assume you are using the SMALL memory model. You have an array in external memory, e.g.:



```
char xdata myArray[6];
```

that contains one-character commands.

**Note** The explicit xdata in the declaration of myArray[] overrides the SMALL memory model's default memory type of data for the variable myArray[].

You pass those commands, one at a time, via a message queue, to another task:

```
OSSignalMsgQ(MSGQ1, (OStypeMsgP) &myArray[i]);
```

Each element of the message queue is a Salvo message pointer of type OstypeMsgP, usually predefined as void \*, i.e. a pointer to anything. The power of using message pointers becomes apparent when you realize that there are no restrictions on what a message pointer can point to. It can point to a char, an int, a const, a structure, another pointer, a function, etc. As long as both parties agree on what a particular message points to, the information will pass correctly from sender to receiver.

In the example above, the messages in the message queue are pointers to an array of char in external memory. The (OStypeMsgP) typecast is used in OSSignalMsgQ() to convert &myArray[i], which is a pointer to a char in external memory, into a message pointer. When another task receives the message, it will have to convert (via another typecast<sup>4</sup>) the pointer back to the appropriate type before dereferencing it:

```
void TaskRcv ( void )
{
    char cmd;
    OStypeMsgP msgP;

    for (;;)
    {
        OS_WaitMsgQ(MSGQ1, &msgP, TaskRcv2);
        cmd = * (char *) msgP; /* wrong! */
...
```

Sadly, the typecast above is not entirely correct. That's because we're asking the Cx51 compiler to convert a message pointer to a char pointer (i.e. a pointer to a char in internal memory), when what we really want is a char xdata pointer! Why? Because myArray[] is located in external memory, and we need the Cx51 compiler to treat msgP as if it's a pointer to a char object in external memory before dereferencing it. The correct line is:



```
cmd = * (char xdata *) msqP;
```

We could have avoided this confusion by defining:

```
typedef char xdata myBanklArray;
by declaring:
   myBanklArray myArray[6];
and by writing:
   cmd = * (myBanklArray *) msgP;
```

when dereferencing the message pointer.

### **Effect of Selecting a Different Memory Model**

In example above, had we declared myArray[6] as char (no xdata), and we used the SMALL memory model, then the simple message pointer dereferencing of cmd = \* (char \*) msgP would have worked properly.

If we then changed to the LARGE model, myArray[] would be located in external memory, and the dereferencing would not work properly at runtime. That's because the change in memory model (SMALL to LARGE) resulted in a change in default memory type (data to xdata), and myArray[] – lacking an explicit memory type in its declaration – follows the default memory type of the memory model selected. Yet the typecast – (char \*) – remained unchanged, still assuming that myArray[] was of type char, not char xdata.

Therefore we recommend explicit memory types and typedefs when any sort of pointer dereferencing is required so as to avoid any problems when changing memory models.

### Conclusion

Your application's RAM objects will be located in the 8051's internal and/or external memory space based on the Cx51 memory model you select and any explicit memory types you employ. If you use pointers to access those objects, or if you use Salvo's messaging services, you need to pay close attention to declarations and typecasts to ensure that your pointers are pointing to what you think they're pointing to. Failing to explicitly declare memory types may lead to problems when switching between memory

## **Application Note**

models.<sup>6</sup> Using typedef can help you avoid certain common mistakes.

### **Acknowledgements**

Dan Henry, for issues surrounding the COMPACT memory model, and others.

### References

Keil Elektronik GmbH. and Keil Software, Inc., *Cx51 Compiler User's Guide*, 5.2001.

<sup>&</sup>lt;sup>1</sup> SMALL is the default and is recommended for most applications.

<sup>2</sup> XX represents the most significant 8 bits of the 16-bit external address and is asserted by P2.

Where n is 0 or 1, i.e. R0 or R1 contains the lower 8 bits of the 16-bit address.

Typecasting is a compile-time, not a real-time operation. Therefore it has no effect on run-time performance per se.

Internal memory / data space because of the SMALL model.

From a performance standpoint, it's best to always explicitly declare the memory types of pointers in C51.